



Universal Dome Lights



PUT-230125 (1.25")



PUT-230150 (1.50")



PUT-230175 (1.75")



194 Bulb



PUT-230194W (white)

3157 Bulb



PUT-234157W (white)
PUT-234157R (red)
PUT-234157A (amber)



194 Bulb



PUT-230194W-360 (white)



WHITE



RED



AMBER



PUTCO PURE L.E.D. 3RD BRAKE LIGHT



LED Third Brake Lights (Replacement)		Clear	Smoke	Ion Chrome
CHEVY / GMC				
2007-11	Chevy Silverado / GMC Sierra	PUT- 900289	PUT- 920289	PUT- 930289
1999-06	Chevy Silverado / GMC Sierra	PUT- 900211	PUT- 920211	PUT- 930211
1994-98	Chevy Silverado / GMC Sierra	PUT- 900207	PUT- 920207	PUT- 930207
2007-11	Chevy Tahoe/Suburban / GMC Yukon(XL)	PUT- 900215	N/A	PUT- 930215
2007-11	Chevy Avalanche	PUT- 900218	PUT- 920218	PUT- 930218
DODGE				
2002-08	Dodge Ram (incl 2009 2500/3500)	PUT- 900256	PUT- 920256	PUT- 930256
1994-01	Dodge Ram	PUT- 900232	PUT- 920232	PUT- 930232
FORD				
2004-08	Ford F150	PUT- 900247	PUT- 920247	PUT- 930247
1999-03	Ford F150	PUT- 900204	PUT- 920204	PUT- 930204
1999-11	Ford Super Duty (also 95-03 Ranger)	PUT- 900206	PUT- 920206	PUT- 930206
NISSAN				
2004-10	Nissan Titan	PUT- 900245	PUT- 920245	PUT- 930245
TOYOTA				
2007-11	Toyota FJ Cruiser	PUT- 900214	N/A	PUT- 930214
2007-10	Toyota Tundra	N/A	N/A	PUT- 930216
1999-06	Toyota Tundra	PUT- 900280	PUT- 920280	PUT- 930280

PUTCO PURE L.E.D. DUALY MARKERS



LED Fender Markers		Clear	Smoke	Ion Chrome
CHEVY / GMC				
1999-10	Chevy Silverado / GMC Sierra Dually	PUT- 900001	PUT- 920001	PUT- 930001
DODGE				
2003-2010	Dodge Ram Dually	PUT- 900056	PUT- 920056	PUT- 930056
FORD				
1999-2011	Ford Super Duty Dually	PUT- 900006	PUT- 920006	PUT- 930006

PUTCO PURE L.E.D. ROOF LAMPS



Upgrade your pickup trucks dull roof top factory running lights with Putco's eye popping complete replacement Pure LED Pickup Truck Cab Roof Top Lights. Putco Pure LED roof top running lights are available for todays top pickups.



LED Roof Lamps (Replacement)		Clear	Smoke	Ion Chrome
CHEVY / GMC				
2002-2006	Chevy Silverado / GMC Sierra - 3pc kit (with lights)	PUT- 900511	PUT- 920511	PUT- 930511
DODGE				
2003-2008	Dodge Ram - 5pc kit (with lights)	PUT- 900556	PUT- 920556	PUT- 930556
1999-2002	Dodge Ram - 5pc kit (with lights)	PUT- 900534	PUT- 920534	PUT- 930534
FORD				
1999-2011	Ford F150 / Super Duty - 5pc kit (lens only)	PUT- 900504	PUT- 920504	PUT- 930504

